

HOW TO PREPARE YOUR WALL



Preparing your wall prior to installation ensures a good adhesion and a quality look and feel. We do not recommend installing your mural without first preparing your wall.

Plastered Walls

1. Ensure the wall is clean and dry with no loose plaster. Use a damp sponge to wash your wall down and let dry fully.
2. To help seal a porous surface, we recommend you seal your wall with a quality primer/sealer

Painted Walls

1. We recommend you install your mural on top of matt emulsion paint only.
2. If your wall has cracked or flakey paint we recommend the surface be correctly prepared with a quality primer/sealer.
3. Freshly painted walls should be left for 2-3 weeks to dry out completely before installing your mural.

Papered Walls

1. We recommend you remove any old wallpaper, if not your mural may not stick to the wall.
2. Do not use a lining paper on your wall - Peel and Stick installations only.