

HOW TO MEASURE YOUR WALL



Always measure the longest & widest parts of your wall, ignoring any slopes. If your wall does have a slope to it, this section can be cut away during installation.



Ignore obstacles such as doors, windows and light sockets, as these can be cut around during installation.



Ensure you measure the entire surface you wish to cover, excluding any skirting boards or coving and we recommend you add an extra 5cm to your dimensions to cover bleed and fitting.

Gallery 68 - 50 Pylewell Rd, Hythe SO45 6AQ
T: +44 02381 782 772 W: www.gallery68.co.uk